

LUBRICUS

User manual
LUB-V (24 VDC)



GRUETZNER
AUTOMATIC LUBRICATION

I. Revision history & imprint

I.I Revision history

The present user manual is the original user manual.

This user manual is only valid for

Product:

Product designation: Lubricus V (LUB-V)
Product revision: ---

User manual:

Date of creation: 12.2019
Revision of the user manual: 1

This document is protected by copyright.

All rights for layout, content, texts and corporate design are reserved by Gruetzner GmbH, © 2019.

All rights, including those of photomechanical reproduction, duplication and distribution by means of special processes (e.g. data processing, data carriers and data networks), even in part and/or in extracts, are reserved by Gruetzner GmbH.

The content and technical specifications are subject to change without notice.

I.II Imprint

Address:

Gruetzner GmbH
Kohlenhofstr. 60
90443 Nuremberg, Germany
Tel: +49 (0)911 277 399-0
Fax: +49 (0)911 277 399-99
info@G-LUBE.com
www.G-LUBE.com

Commercial Register of Nuremberg Local Court: HRB 12109

USt.-ID: DE 160441123

CEO: Volker Grütznér

I.II Table of contents

Chapter	Content	Page
I.	Revision history & imprint	02
I.I	Revision history	02
I.II	Imprint of the manufacturer, distribution and service	02
I.III	Table of contents	03
1.	General information about this manual	06
1.1	Signal words	06
1.2	Warning symbols	07
1.3	Structure of the safety instructions	07
1.4	Symbols for information	07
2.	Safety	08
2.1	EC/EU Directive	08
2.2	Hazards	08
2.3	Staff	08
2.4	Reasonably predictable misuse	08
2.5	Usage for the intended purpose	09
2.6	Warranty and Liability	09
2.7	General safety instructions	10
3.	Description of function	11
3.1	General information	11
3.2	Nameplate and designation	12
3.3	Scope of delivery	12
3.4	Technical data	13
4.	Transport and storage	14
4.1	Packaging	14
4.2	Transport	14
4.3	Storage	14
5.	Mounting	15
5.1	Preparations	15
5.2	Assembly	15
5.3	Commissioning	19

Chapter	Content	Page
6.	Operation and settings	20
6.1	General information	20
6.2	Factory settings	21
6.2.1	Default settings hour mode -h-	21
6.2.2	Default settings, operating mode: empty time mode Et	22
6.2.3	Pulse control mode PUL	22
6.3	Menu and LCD messages	23
6.3.1	LCD	26
6.3.2	Actions with the activation and programming key	29
6.3.3	Switching on and off	31
6.3.4	INF menu, operating mode: hour mode -h-	32
6.3.5	INF menu, operating mode: empty time mode Et	33
6.3.6	INF menu, operating mode: impulse mode PUL	34
6.3.7	SET menu	35
6.3.8	RUN menu	37
6.3.9	PRO menu, operating mode: hour mode -h-	38
6.3.10	PRO menu, operating mode: empty time mode Et	41
6.3.11	PRO menu, operating mode: impulse mode PUL	43
6.3.12	FIL menu	44
6.4	Error codes	45
7.	Input and output signals - time control	46
7.1	Pin assignment	46
7.2	Output signals and LCD messages	46
7.3	Output signals at PIN 4	48
8.	Input and output signals - external control (PLC)	48
8.1	Pin assignment	48
8.2	Input signals	49
8.2.1	Control signal 2 seconds	50
8.2.2	Control signal 12 seconds	52
8.2.3	Control signal 14 seconds	54
8.3	Output signals/LCD messages	56
8.3.1	Error E1 (empty level)	57
8.3.2	Error E2 (overload)	59
8.3.3	Error E3 (undervoltage)	60
8.3.4	Error E4 (fatal error)	61

Chapter	Content	Page
9.	Maintenance and disposal	62
9.1	Maintenance schedule	62
9.1.1	Visual check	63
9.1.2	Cleaning	63
9.1.3	Recommissioning after maintenance	63
9.2	Cartridge change	64
9.3	Disposal	67
10.	Released accessories	68
10.1	Lubricants	69
10.2	Tube lengths	69
11.	Appendix	70
11.1	Dimension sheet and installation dimensions	70
11.2	EC/EU declaration of conformity	71
11.3	Spare parts	72
11.4	Flowchart pulse control mode PUL	73

1. General information about this manual

This user manual contains all necessary information to use Lubricus V (24 VDC version), hereinafter referred to as LUB-V, safely and as intended. In the event that supplementary sheets are attached to these instructions, the information and data contained there are valid and replace the corresponding information in this user manual. Any contradictory information contained in this user manual thus becomes invalid. If you have any questions regarding special applications, please contact Gruetzner GmbH (chapter I.II).

The actual and factual operator must ensure and guarantee that these instructions, including any supplementary sheets, have been read and understood by all persons responsible for the installation, operation or maintenance of LUB-V. Therefore, keep these instructions in a suitable place, ideally in an easily accessible place in the surrounding area of LUB-V.

Inform your colleagues who work in the local area of the machine about safety instructions so nobody gets hurt.

This manual was written in German, all other language versions are translations of this manual.

1.1 Signal words

The following signal words are used in this manual to draw your attention to possible dangers, prohibitions and other important information:

DANGER

This signal word points you to an immediate and threatening risk of serious injury or death.

WARNING

This signal word indicates a potentially imminent danger which can result in serious injury or even death.

CAUTION

This signal word indicates a potentially imminent danger that can result in minor to severe injuries.

NOTICE




This signal word indicates a potentially imminent danger which can result in damage to property.

INFORMATION

This signal word refers to practical application tips or particularly important information when using LUB-V.


1.2 Warning symbols

The following warning symbols are used in this user manual to alert you to hazards, prohibitions and important information:

		
General warning sign	Electricity hazard	Flammable material




1.3 Structure of the safety instructions

The safety instructions in this user manual are structured according to the following system:

	CAUTION
	<p>This text explains the consequences of disregarding the reference.</p> <ul style="list-style-type: none"> This text shows what to do as an instruction.

1.4 Symbols for information

The following information symbols are used in the text and instructions in this manual:

-  Requests you to take action
-  Shows the consequences of an action
-  Additional information about the action

2. Safety

All persons working with LUB-V must follow these operating instructions, in particular the safety instructions and the rules and regulations applicable at the place of use. Generally applicable legal regulations and other rules as well as the relevant rules and regulations for accident prevention (e.g. personal protective equipment (PPE)) and environmental protection must be observed.

2.1 EC/EU Directive

Within the scope of the EC/EU Directive, (re)commissioning of a machine on which LUB-V has been installed and/or fitted is prohibited until it has been clearly established that the machine complies with the provisions of the applicable directive. An EC/EU declaration of conformity for LUB-V can be found in the appendix (chapter 11.2).

2.2 Hazards

In order to avoid danger to the user or damage to the machine on which LUB-V is used, LUB-V may only be used for its intended purpose (chapter 2.5) and in a technically safe condition.

Always inform yourself about the general safety instructions (chapter 2.7) before starting to work.

2.3 Staff

Only qualified staff who has read and understood this manual may work with LUB-V. Local and/or company regulations apply accordingly.

2.4 Reasonably predictable misuse

Any use of LUB-V which exceeds the maximum permissible technical data is generally considered to be improper and therefore prohibited.

2.5 Usage for the intended purpose

The following points must be observed for the intended purpose of using LUB-V:

- LUB-V is exclusively approved for industrial use.
- LUB-V may be used in accordance with the technical data (chapter 3.4) exclusively.
- Unauthorized structural alterations to LUB-V are not permitted.
- Read the user manual and act accordingly.
- During operation of LUB-V, a visual inspection of LUB-V as well as of the lubrication point must be carried out regularly. Any anomalies must be eliminated immediately and the cause must be rectified.
- Refilling the cartridge is not permitted.
- LUB-V may not be opened or disassembled.
- Only lubricants approved by the manufacturer may be used.
- Relevant regulations and rules on work safety, accident prevention and environmental protection must be observed.
- Work and activities with and on LUB-V are only permitted with appropriate authorization (chapter 2.3).

All other uses than the aforementioned intended usage or the disregard of one of the above points shall be deemed improper usage. In this case no liability and/or warranty is assumed.






2.6 Warranty and Liability

If the following items are disregarded, all warranty and liability claims for personal injury and/or damage to property are excluded:

- non-observance of the instructions on transport and storage;
- misuse;
- improper or unperformed maintenance or repair work;
- improper assembly / disassembly or improper operation;
- operation of LUB-V with defective protective devices;
- operation of LUB-V without lubricant;
- operation of LUB-V with non-approved lubricant;
- operation of heavily contaminated LUB-V;
- modifications or alterations which may be carried out without the written permission of Gruetzner GmbH have taken place;
- opening and/or partial or complete disassembly of LUB-V.

1.2 General safety instructions

The following safety instructions are given for LUB-V:

	<p style="text-align: center;">DANGER</p> <p>Damaged or flawed electrical connections or unlicensed hot components lead to heavy injuries or even death.</p> <ul style="list-style-type: none"> • All work on electrical connections shall be provided by qualified personnel only. • Immediately change damaged cables or plugs.
	<p style="text-align: center;">NOTICE</p> <p>Loose or overloaded screw connections can cause damage to LUB-V.</p> <ul style="list-style-type: none"> • Mount and check all screw connections with the permissible torques specified for this purpose. Use a calibrated torque wrench.
	<p style="text-align: center;">WARNING</p> <p>Lubricants are flammable.</p> <ul style="list-style-type: none"> • In case of fire do not use a water jet to extinguish. • In case of fire only use suitable extinguishing agents such as powder, foam and carbon dioxide. • Observe the relevant safety instructions of the lubricant manufacturer on the safety data sheet of the lubricant used.
	<p style="text-align: center;">CAUTION</p> <p>Lubricants can cause skin irritations.</p> <ul style="list-style-type: none"> • Avoid direct skin contact.
	<p style="text-align: center;">NOTICE</p> <p>Lubricants can contaminate soil and water.</p> <ul style="list-style-type: none"> • Use and dispose lubricants properly.

3. Description of function

3.1 General information

LUB-V is designed as an extremely compact double piston pump. The two pistons run force-controlled and counter-rotating. LUB-V is available with one or two lubricant outlets. The outlets are secured by an integrated non-return valve. Approx. 0.16 cm³ of lubricant is pumped during each dispensing operation; multiple dispenses can be set one after the other.

The LCD on the front panel displays the various operating states; further information (empty cartridge, error) can be read.

The present Lubricus V as 24 VDC version has an electrical interface. The supplied activation and programming key can be used to adjust the operating mode and the quantity of lubricant pumped per time to supply the lubrication point with the ideal quantity of lubricant.




Fig. 1: Overview LUB-V

No.	Description
0	Lubricus V (LUB-V)
1	LCD
2	Action area (for actions with the activation and programming key)
3	Activation and programming key
4	Lubricant outlet(s) (different versions available)
5	Retaining ring
6	Housing
7	M12x1 electrical interface
8	Nameplate with designation, CE mark and serial number
9	Clearance hole for assembly
10	Lubricant inlet with thread for cartridge

3.2 Nameplate and designation

The nameplate of LUB-V is visibly attached to the side of the pump itself. There the CE mark and the serial number of LUB-V are visible. Refer to chapter 3, Fig. 1 for the location of the nameplate and serial number.

3.3 Scope of delivery

LUB-V is available in several different versions. They differ in the number and type of lubricant outlets and the scope of accessories supplied.

3.4 Technical data

Housing			
dimensions without cartridge	width x height x depth	107 x 56.5 x 108	mm
dimensions with cartridge 400 ml		107 x 198.5 x 108	
weight (without cartridge)	appx.	1050	g
mounting options		holes for screw M6	
mounting position		upright	
material housing		zinc die-cast / PA 6.6 GF30 / POM	
material outlet		nickel-plated brass	
operating temperature		-15 ... +60*	°C
Lubricant and hydraulic			
cartridge volume		400	cm ³
lubricant characteristics		oils and greases up to NLGI 2	
number of outlets		1 / 2	
hydraulic connection		via PA tube	
number of lubrication points		without accessories: up to 2* with splitters: up to 8* with progressive distributors: up to 40*	
max. pressure		70 (-10%/+15%)	bar
steady state pressure		50	bar
grease delivery	per stroke	0.16 (-5%)	cm ³
Electrics			
display		LCD	
operating voltage		24 (+/- 5%)	V
protection		0.75 (slow blow)	A
protection class		IP 54	
current draw		$I_{\max} < 0.3$ $I_{\text{rest}} < 0.025$	A
Please see chapters 7 and 8 for more information about electrics.			

* The stated value is down to the individual application and may extensively differ in some cases (depending on the lubricant and further conditions).

4. Transport and storage


4.1 Packaging

LUB-V is delivered in an outer packaging (cardboard box) and - depending on the scope of delivery - with a lubricant cartridge and other accessories in the same package. To protect them from moisture and dirt they are also packed in PE films.

Dispose the packaging materials at designated disposal points in compliance with the relevant national and company regulations.

After receiving LUB-V check the delivery note for completeness and correctness. Any missing parts or damages must be reported immediately to the forwarding agent, the insurance company or Gruetzner GmbH in writing.

4.2 Transport

NOTICE	
	<p>Hard shocks due to e.g. falling or setting down too hard can damage LUB-V.</p> <ul style="list-style-type: none"> • Do not throw LUB-V. • When using lifting equipment only use hoists and load handling attachments in perfect condition and with sufficient load capacity. • The permissible lifting weight of the lifting device must not be exceeded.

4.3 Storage


Store LUB-V in its original packaging in a vertical position in a dry, frost-free environment at an ambient temperature of +5 °C to +30 °C. The maximum storage time in unopened condition is 2 years.

The so-called "first-in-first-out" principle (fifo) is recommended for storage logistics.

5. Mounting

5.1 Preparations


Before starting to work, inform yourself in detail about LUB-V using this user manual; and follow the general safety instructions (section 2.7) in particular. Prepare the installation site carefully.

	NOTICE
	<p>Pressurised air can damage the seals of LUB-V and can transport dirt and foreign matter into LUB-V or the lubricant.</p> <ul style="list-style-type: none"> • Do not use pressurised air. • Make sure that there is no coarse dirt in the mounting area.


5.2 Assembly

1	<p>Condition as delivered</p> <p>LUB-V is delivered in a cardboard box. Depending on the version ordered further accessories such as battery, lubricant cartridge or brackets are included. It also contains a short manual for experienced users to start up and assemble the unit for the first time.</p>
---	--

2	<p>Remove housing from power unit</p> <p>✦ Separate the housing from the power unit by turning the retaining ring counterclockwise.</p> <p>ⓘ Make sure that no dirt, water or foreign bodies enter the lubricant inlet.</p>
---	--



3




Remove cartridge cap

✦ Turn the cap of the lubricant cartridge counterclockwise and pull it off.

ⓘ Pay attention to cleanliness when carrying out the work. Be sure to prevent dirt, liquids and foreign bodies from entering the cartridge.

4




Mount lubricant cartridge

- ✦ Place the full lubricant cartridge on LUB-V (label facing front).
- ✦ Turn the lubricant cartridge clockwise onto LUB-V.

ⓘ The end position is reached after two full rotations when the label of the lubricant cartridge is aligned with the front of LUB-V.

5



Assemble housing on power unit


- ✦ Place the dismantled housing on LUB-V and press it onto the power unit.
- ✦ Fasten the housing to the power unit by turning the retaining ring clockwise.

ⓘ The retaining ring must snap into place when turning and be completely tightened.

6

Remove protective cap on the side of LUB-V


✦ Remove the black protective cap from the electrical interface on the side of LUB-V.



7

Connect electrical interface

✦ To connect LUB-V with an external power supply system add a proper connecting cable to the electrical interface on the side of LUB-V.



ⓘ Depending on the application connecting cables with both straight or angled sockets can be used.

ⓘ For more details on connecting cables please see chapter 8.1.

DANGER



Damaged or flawed electrical connections or unlicensed hot components lead to heavy injuries or even death.

- All work on electrical connections shall be provided by qualified personnel only.
- Immediately change damaged cables or plugs.
- Before working on electrical installations, always follow the five safety regulations of electrical engineering:
 - Isolate
 - Protect against accidental restart
 - Ensure all parts are deenergized
 - Ground and short-out
 - Cover nearby hot components

5.3 Commissioning

Mount LUB-V carefully according to the steps described in chapter 5.2. Depending on the scope of delivery you must also carry out the following additional measures for first-time commissioning:

1. Mechanical fastening

Fix LUB-V mechanically. Pay particular attention to the maximum tightening torques.

2. Electrical connection

Connect LUB-V with an external power supply system (e.g. PLC) by adding a proper connecting cable to the electrical interface on the side of LUB-V.

3. Check the assembly

Make sure that LUB-V is assembled properly and completely. In particular, the external power supply system has to be connected and a lubricant cartridge must have been fitted.

4. Power on

If you want to put LUB-V into operation, switch on LUB-V. LUB-V only delivers lubricant to the lubrication point according to the settings when switched on. The detailed description for powering on can be found in chapter 6.3.3.

5. Execute FIL function

Execute the FIL function. The detailed description can be found in chapter 6.3.9. LUB-V performs a certain number of strokes and transports lubricant from the cartridge to the outlet.

6. Hydraulic connection

Connect the consumer hydraulically to LUB-V. If you connect tubes to LUB-V make sure that tubes and connectors are installed tightly, cleanly and correctly.

① Ideally, use tubes prefilled with the appropriate lubricant.

7. Check the settings on LUB-V

Check the required values for the lubrication point at the factory settings of LUB-V and adjust them if necessary. changes at LUB-V can be made in the SET menu, chapter. 6.3.7, and in the PRO menu, chapter 6.3.9 to 6.3.11.

6. Operation and settings

6.1 General information

What you should know about operating and setting LUB-V:

✓LUB-V is suitable as a multi-point lubricator for one or two lubrication points. However, depending on the specific application, LUB-V can also reliably and cleanly supply a limited number of lubrication points with lubricant. Accessories from the manufacturer (e. g. splitters or progressive distributors) can be connected to LUB-V. If necessary, changes must be made to LUB-V settings to ensure safe and reliable operation.

✓LUB-V is a cycle controlled lubricator which works time-based via the integrated micro-electronics and is connected to a 24 VDC power supply. LUB-V cyclically delivers a defined quantity of lubricant from the cartridge to the outlet. Three operation modes can be selected.

Hour mode -h- allows setting the number of cycles (c) and a pause time (h) between two dispensing cycles in hours. Pause times (h) between 1...240 hour(s) and cycles (c) between 1...30 can be set.

The **empty time mode Et** allows the emptying time of the cartridge to be set in months. Emptying times between 1...36 month(s) can be set.

Additionally, LUB-V can be embedded into a programmable logic controller (PLC) which sends orders and controls LUB-V in **impulse mode** (see chapters 6 and 8). How to switch to operation mode PUL is described in detail in chap. 6.3.8.

✓A dispensing cycle consists of at least one (1) dispense (stroke) and can consist of a maximum 30 dispenses. Up to 30 dispenses per outlet are made in direct succession. After the end of the lubrication cycle LUB-V rests until the set pause time h has elapsed and then automatically carries out the next lubrication cycle.

✓The disposable interchangeable cartridge with 400 ml lubricant guarantees a controlled and constant quality of the lubricant and is filled bubble-free. LUB-V allows a high supply security of the lubrication point and prevents failures.

✓LUB-V cannot be used without a lubricant cartridge. Depending on the version ordered the cartridge can already be included in the scope of delivery and may already be connected and installed in LUB-V.

✓ The respective conditions of LUB-V can be seen in the LCD. It additionally enables the optical recognition of the condition by means of coloured LEDs.

✓If you have any questions about your application and the correct settings for LUB-V please contact the manufacturer (chapter I.II).

6.2 Factory settings

LUB-V is always delivered with the following factory settings:

operating mode:	hour mode -h-	
mode:	OFF	LUB-V is switched off

① The factory settings provide the use of LUB-V in hour mode -h-. If you would like to operate LUB-V in empty time mode Et or impulse mode PUL you have to make changes in the SET menu of LUB-V.

6.2.1 Default settings, operating mode: hour mode -h-

Pause time	h = 3	The pause time is 3 hours.
Number of cycles	c = 1	The number of cycles is one (1) stroke per outlet.

① The default settings in hour mode when using a LUB-V with one (1) lubricant outlet result in an emptying time (service life) of 313 days (= 10 months) for a full 400 ml lubricant cartridge, provided that LUB-V is permanently switched on and no special dispenses have been made. Within approx. 3 hours, LUB-V will deliver one dispense per stroke (0.16 cm³).

① If you are using LUB-V with one (1) lubricant outlet, one dispensing stroke will be delivered from one outlet at the end of the pause time. If you are using LUB-V with two (2) lubricant outlets, one stroke per outlet will be delivered at the end of the pause time. The emptying time of the cartridge is halved.

✦ Verify that the default settings are appropriate for your application and that the lubrication point is supplied with the correct amount of lubricant per time unit. If this is the case, you can operate LUB-V with the default settings in hour mode -h-.

If this is **not** the case change the values for the pause time h and number of cycles c accordingly; see chapter 6.3.7 for an explanation of how to make these changes.

① To use LUB-V it must be properly mounted and installed first and then switched on. The installation is very simple and is described in detail in chapter 5.2; switching on is described in chapter 6.3.3.

① If you order a factory-provided special version of LUB-V, the information contained in the supplement is authoritative.

6.2.2 Default settings, operating mode: empty time mode Et

Emptying time $E_t = 6$ The emptying time of one (1) cartridge is 6 months.

ⓘ The default settings in empty time mode result in an emptying time (service life) of 6 months for a full 400 ml lubricant cartridge, provided that LUB-V is permanently switched on and no special dispenses have been made.

✦ Verify that the default settings are appropriate for your application and that the lubrication point is supplied with the correct amount of lubricant per time unit. If this is the case, you can operate LUB-V with the default settings in empty time mode Et.

If this is **not** the case change the values for the emptying time t accordingly.

ⓘ To use LUB-V, it must first be properly mounted and installed and then switched on. The installation is very simple and is described in detail in chapter 5.2; switching on is described in chapter 6.3.3.

ⓘ If you order a factory-provided special version of LUB-V, the information contained in the supplement is authoritative.

6.2.3 Default settings, operating mode: impulse mode PUL

Impulse mode PUL enables embedding LUB-V in an external control (PLC) to command and control the device. The number of strokes (one stroke=0,16 cm³) dispensed now depend on the PLC's signals.

✦ Ensure that your PLC program is appropriate for your application and that the lubrication point is supplied with the correct amount of lubricant per time unit.

If this is the case, you can operate LUB-V in impulse mode PUL.

If this is **not** the case, change settings of your PLC.

ⓘ To use LUB-V it must first be properly mounted and installed and then switched on. The installation is very simple and is described in detail in chapter 5.2; switching on is described in chapter 6.3.3.

ⓘ If you order a factory-provided special version of LUB-V the information contained in the supplement is authoritative.





6.3 Menu and LCD messages


The LCD of LUB-V can be used to read information, to change settings with the activation and programming key on the top of LUB-V or to trigger individual actions.

Generally, settings can be changed and actions can be triggered when LUB-V is switched off (OFF) and when it is switched on (ON).

The individual submenus are presented, described and explained in detail in chapters 6.3.4 to 6.3.12.

The symbolic representations used below are described as follows:

Symbol	Description	Note	Chapter
	LCD display	The LCD displays information both during operation and for programming purposes.	6.3.1
	Sequence arrow	The black sequence arrow indicates the unchangeable basic structure of the menu.	./.
	Action arrow	The blue action arrow shows the consequence of touching the action area with the activation and programming key.	6.3.2
	Submenu	In the respective submenu's information can be read, dispensing processes can be initiated and settings can be changed.	6.3.4 to 6.3.12



The graphic above illustrates the unchangeable basic flowchart of the LUB-V menu navigation as well as the options for branching to submenus.

① LUB-V can be switched on and off at several points in the menu navigation. For details see chapter 6.3.3.

① The INF menu can only be accessed from OFF mode (LUB-V is switched off). The INF menu provides you with an informative overview of the current LUB-V settings. For details see chapter 6.3.4 and 6.3.5.

① The SET menu can only be accessed from OFF mode (LUB-V is switched off). The SET menu allows you to make changes to the operating mode. Details can be found in chapter 6.3.6.

① The RUN menu can only be accessed from ON mode (LUB-V is switched on). The RUN menu allows you to manually trigger a single dispense at LUB-V. For details see chapter 6.3.7.


ⓘ The PRO menu is only accessible from ON mode (LUB-V is switched on). The PRO menu allows you to make changes to the LUB-V settings - and thus to its dispensing behavior. For details see chapter 6.3.8 and 6.3.9.







ⓘ The FIL menu is only accessible from ON mode (LUB-V is switched on). The FIL menu allows you to manually trigger a fixed number of dispenses at LUB-V. For details see chapter 6.3.10.

6.3.1 LCD

The LCD displays information about various states of LUB-V.

Depending on the state of the LUB-V you will be supported by three coloured LEDs to the right of the LCD. This allows you to assess the condition of LUB-V from a distance. Basic meanings: green=OK; red=error. The following tables show the LED assignment on the LCD as well as the explanation of the respective output.

LCD	Assignment
	upper LED: red middle LED: yellow lower LED: green

LCD	Description	Naming	Chapter
	The red LED only lights up if there is an error.	Error on LUB-V	6.4
	The yellow LED only lights up if the activation and programming key has touched the action surface (activation and programming key detected).	Activation and programming key detected by LUB-V	6.3
	The green LED lights up during a dispensing process for approx. 7...17 seconds.	LUB-V dispenses lubricant	6.3
	The green LED lights up when changes are possible and the activation and programming key was previously detected.	Changes possible	6.3
	The green LED flashes every 5 seconds when LUB-V is ON and no error occurs.	LUB-V is ready for use	6.3
	The green LED flashes twice when a value has been confirmed. Additionally the LCD also flashes twice.	Acceptance of changed value	6.3


Display in LCD	Meaning	Chapter	
<i>no display</i>	Power supply not connected	5.3	
OFF	LUB-V is switched off	6.3.3	
On	LUB-V is ready for operation; LUB-V dispenses lubricant in accordance to the operating mode and the values set	6.3.3	
PUL	LUB-V is ready for operation in impulse mode PUL and waits for control signals from the PLC	8	
PUL (flashing)	LUB-V is receiving a control signal from the PLC	8	
---	Received control signal longer than 15 seconds	8.2	
Errors			
E1	Error E1 (empty cartridge)	6.4	
E2	Error E2 (overload / overpressure)	6.4	
E3	Error E3 (undervoltage)	6.4	
E4	Error E4 (fatal error)	6.4	
Submenus			
INF	INF menu		6.3.4 6.3.5
	b01	Firmware version of LUB-V	
	h03	Currently set value of pause time h	
	c01	Currently set value of number of strokes c	
	6	Currently set value of emptying time Et	
	PUL	Currently set operating mode: impulse mode	
SET	SET menu		6.3.7
	-h-	Operating mode: hour mode	
	Et	Operating mode: empty time mode	
	PUL	Operating mode: impulse mode	
RUN	RUN menu		6.3.6
	01...70	During the manually triggered active RUN command ("Quick check"/extra dispense), the LCD displays the approximate back pressure in bar. In addition, the green LED lights up.	

PRO	PRO menu		6.3.7
	h1...99	Adjustable setting of pause time h	
	c1...30	Adjustable setting of number of strokes c	
	1...36	Adjustable setting of emptying time Et	
	PUL	Currently set operating mode: impulse mode No changeable value	
FIL	FIL menu		6.3.9
	01...70	During the manually triggered, active FIL command, the LCD displays the approximate back pressure in bar. In addition, the green LED lights up.	
	Clr	If the process is aborted during the FIL command Clr appears at first.	
Additional characters on the LCD			
1 / 2	During a dispensing process LUB-V indicates from which outlet lubricant is being pumped.		
MAX	After each cycle the maximum back pressure is displayed in bar.		

6.3.2 Actions with the activation and programming key

The activation and programming key attached to the top of LUB-V allows you to perform actions and changes in the settings of LUB-V. This activation and programming key can be easily and permanently stored on top of LUB-V.


1



Remove the key

- ✦ Turn the activation and programming key to the OPEN position and remove it from the housing of LUB-V.
- ⓘ The activation and programming key is stored in the opening on the top of the housing of LUB-V. It is also used to seal LUB-V.

2



Guide the activation and programming key to the action area


- ✦ Place the activation and programming key on the action area on the front of LUB-V.
- ➡ As soon as the activation and programming key on the action area has been detected by LUB-V, the yellow LED lights up. The menu flashes in a rhythm of approx. 2 seconds.
- ✦ Remove the activation and programming key from the action area as long as the desired menu item is displayed in the LCD.
- ➡ The yellow LED disappears. You have performed an action. The LCD and the green LED flash twice.

✦ At the end of the action or setting reinsert the activation and programming key into the hole provided on the housing of LUB-V. Then turn the activation and programming key to the CLOSE position to restore the sealing effect.

ⓘ Please note, however, that in the event of faults or changes to be made no changes or actions can be carried out on LUB-V without the activation and programming key. If you reattach the activation and programming key to the housing of LUB-V after carrying out actions on LUB-V it is ensured that no dirt can get into the housing. The activation and programming key must be reinserted in the housing of LUB-V after actions have been performed.

6.3.3 Switching on and off

Switching on LUB-V:




✓ LUB-V is switched off (OFF).

✦ Hold the activation and programming key onto the action surface. The yellow LED lights up. Leave the key on the action area until ON is displayed in the LCD. Remove the activation and programming key from the action area as long as ON is displayed. The yellow LED disappears; the LCD and the green LED flash twice.

⇒ If no error is detected during the LUB-V self-check, ON is displayed in the LCD. The green LED lights up once every 5 seconds, LUB-V is ready for operation and will dispense lubricant according to the set values.

✦ Insert the activation and programming key into the hole provided on top of LUB-V.

Switching off LUB-V:



✓ LUB-V is switched on (ON), the green LED flashes every 5 seconds.

✦ Hold the activation and programming key onto the action surface. The yellow LED lights up. Leave the activation and programming key on the action area until OFF is displayed in the LCD. Remove the activation and programming key from the action area as long as OFF is displayed. The yellow LED disappears; the LCD and the green LED flash twice.

⇒ LUB-V is OFF; OFF appears in the LCD. LUB-V stops dispensing lubricant.


✦ Insert the activation and programming key into the hole provided on top of LUB-V.

ⓘ LUB-V can be switched off in any state (normal operating state or error) in the manner described above.

6.3.4 INF menu: operating mode = hour mode -h-

The INF menu informs the user about the firmware used in LUB-V and the settings made earlier and are currently active (values of the adjustable variables t and c that can be changed in the PRO menu).

In INF menu nothing can be changed by the user. The values of the parameters are displayed in a fixed order.



n alphanumerical name of the LUB-V firmware

h set value of variable *h* pause time

c set value of variable *c* number of cycles

✦ Remove the activation and programming key from the top of LUB-V and place it onto the action area.

✦ Hold the activation and programming key onto the action surface. The yellow LED lights up. Leave the activation and programming key on the action area until INF is displayed in the LCD. Remove the activation and programming key from the action area as long as INF is displayed. The yellow LED disappears; the LCD and the green LED flash twice.

↻ The LCD informs you on the set values.


✦ Insert the activation and programming key into the hole provided on top of LUB-V.

ⓘ The INF menu can only be accessed from OFF mode (LUB-V is switched off). When you have entered the INF menu, you will return to OFF mode.

6.3.5 INF menu, operating mode: empty time mode Et

The INF menu is used to inform the user about the firmware used in LUB-V and the settings made earlier and are currently active (value of the adjustable variable Et that can be changed in the PRO menu).

In the INF menu nothing can be changed by the user. The values of the parameters are displayed in a fixed order.



n alphanumerical name of the LUB-V firmware

Et set value of the variable *Et* emptying time in months

400 set value of the size of the lubricant cartridge

✦ Remove the activation and programming key from the top of LUB-V and place it onto the action area.

✦ Hold the activation and programming key on the action surface. The yellow LED lights up. Leave the activation and programming key on the action area until INF is displayed in the LCD. Remove the activation and programming key from the action area as long as INF is displayed. The yellow LED disappears; the LCD and the green LED flash twice.

➡ The LCD informs you on the set values.


✦ Insert the activation and programming key into the hole provided on top of LUB-V.

ⓘ The INF menu can only be accessed from OFF mode (LUB-V is switched off). When you have entered the INF menu, you will return to OFF mode.

6.3.6 INF menu: operating mode = pulse control mode PUL

The INF menu is used to inform the user about the firmware used in LUB-V and the settings which have been made earlier and are currently active.

In INF menu nothing can be changed by the user. The values of the parameters are displayed in a fixed order.



n alphanumerical name of the LUB-V firmware

PUL set operating mode: impulse mode (PUL)

c value of the number of cycles *c* (irrelevant in pulse control mode)

✦ Remove the activation and programming key from the top of LUB-V and place it onto the action area.

✦ Hold the activation and programming key on the action surface. The yellow LED lights up. Leave the activation and programming key on the action area until INF is displayed in the LCD. Remove the activation and programming key from the action area as long as INF is displayed. The yellow LED disappears; the LCD and the green LED flash twice.


➡ The LCD informs you on the set values.

✦ Insert the activation and programming key into the hole provided on top of LUB-V.

ⓘ The INF menu can only be accessed from OFF mode (LUB-V is switched off). When you have entered the INF menu, you will return to OFF mode.

6.3.7 SET-Menu

The SET menu allows you to change the operating mode of LUB-V. You can switch between **hour mode -h-**, **empty time mode Et** and **impulse mode PUL**. The hour mode -h- allows you to set the number of cycles (c) within a dispensing time (h) in hours. The empty time mode Et allows you to set the emptying time (Et) of the cartridge in months. The impulse mode allows you use a PLC to control LUB-V when embedded. Cycles (c) and dispensing time (h) or emptying time (Et) can be adjusted after selecting the operating mode in the PRO menu, see chapters 6.3.9 to 6.3.11.



- h- Operating mode: hour mode -h-
- Et Operating mode: empty time mode Et
- PUL Operating mode: impulse mode PUL

- ✓ LUB-V is switched off (OFF)
- ✦ Remove the activation and programming key from the top of LUB-V and place it onto the action area.
- ✦ Hold the activation and programming key onto the action surface. The yellow LED lights up. Leave the activation and programming key on the action area until SET is displayed in the LCD.
- ✦ Remove the activation and programming key from the action area.
- ⌚ The yellow LED disappears; the LCD and the green LED flash twice. The LCD displays the operating mode currently set. Now you are able to change the operating mode.

Changing the operating mode:

✦ If you would like to change the operating mode, move the activation and programming key back to the action area.

➡ The yellow LED lights up and the LCD displays the currently unselected operating mode. The yellow LED lights up as long as the activation and programming key is on the action surface; the two adjustable operating modes run alternately.

✦ When your desired operating mode is displayed on the LCD, remove the activation and programming key from the action area.

➡ The yellow LED disappears; the LCD and the green LED flash twice. The selected operating mode has now been accepted.

Not changing the operating mode:

✦ If you do not want to change operating mode, the activation and programming key must remain removed from the action area.


➡ The LCD and the green LED flash twice whereby the operating mode is displayed in the LCD.

ⓘ The SET menu can only be accessed from OFF mode (LUB-V is switched off). When you have entered the SET menu, you will return to OFF mode.

6.3.8 RUN menu

The RUN menu is used to manually activate LUB-V and enables triggering an extra dispense. This function can be used, for example, to manually check the condition of the lubrication point ("quick check").

LUB-V carries out a special dispense after triggering the RUN function. After triggering the RUN function, LUB-V executes exactly as many strokes per outlet as were set in the variable number of cycles c in the PRO menu. During the stroke, the back pressure detected by the integrated microelectronics is displayed in the LCD as an approximate value in bar.



✓ There is no fault or error at LUB-V.

✦ Remove the activation and programming key from the top of LUB-V and place it onto the action area.

✦ Hold the activation and programming key onto the action surface. The yellow LED lights up. Leave the activation and programming key on the action area until RUN is displayed in the LCD. Remove the activation and programming key from the action area as long as RUN is displayed. The yellow LED disappears.

➡ The LCD and the green LED flash twice. LUB-V starts to pump the lubricant to the outlet (extra dispense or "Quick check") depending on the value c set in PRO menu. (E.g. if $c=1$ is set, the RUN function triggers one stroke. If $c=4$ is set, 4 strokes are dispensed.)

✦ Insert the activation and programming key into the hole provided on top of LUB-V or repeat the extra dispense ("Quick check") if necessary.

✦ Observe the back pressure values displayed on the LCD if they are of interest.

ⓘ During the dispensing process, the green LED lights up; in addition, the counterpressure for the stroke is displayed in the LCD.


ⓘ In empty-time mode -Et- LUB-V dispenses one stroke.

ⓘ The RUN menu can only be reached from the ON mode (LUB-V switched on). When you have entered the RUN menu, you will return to the ON mode.

6.3.9 PRO menu: operating mode = hour mode -h-

The PRO menu allows you to change the settings of LUB-V's dispensing behavior as well as the operation mode. You can change the pause time h and the number of cycles c (number of strokes).

After pause time h has expired LUB-V executes exactly the number of strokes c (each 0.16 cm³) specified in the number of cycles c.



✓ There is no fault or error at LUB-V.

Being in PRO menu the first step is to set the pause time h and afterwards the number of cycles c; direct access to the number of cycles c is not possible.

✦ Remove the activation and programming key from the top of LUB-V and place it onto the action area. Hold the activation and programming key onto the action surface. Leave the activation and programming key on the action area until PRO is displayed in the LCD.

✦ Remove the activation and programming key from the action area as long as PRO is displayed.

⌚ The LCD and the green LED flash twice. The LCD first displays the value of pause time h (h_s) currently set. Now you are able to change the values of pause time h.

Changing the value of pause time h:

✦ If you would like to change the value of pause time h move the activation and programming key back to the action area.

➡ In the LCD the next higher ($h_{is} + 1$) adjustable value of pause time h is displayed. The green LED lights up as long as the activation and programming key is placed on the action surface; the other values of pause time h run through one after the other. However, you can also remove the activation and programming key from the action area and bring it back there shortly afterwards to reach each value one after the other. If the final value of the pause time h of $h=240$ is reached and no value has been selected the menu returns to $h=01$ and the cycle can be restarted.

✦ As long as the new chosen value you choose for pause time h (h_{new}) is displayed in the LCD remove the activation and programming key from the action area.

➡ The yellow LED disappears, the green LED and the LCD flash twice. The selected new value ($h_{new} = h_{is}$) of pause time h has now been accepted. The submenu will now automatically take you to the values of the number of cycles c.

No changing of the value of pause time h:

✦ If you do not want to change the value of pause time h the activation and programming key must remain removed from the action area immediately after entering the PRO menu.

➡ The LCD as well as the green LED flash twice and the pause time h is displayed in the LCD. The submenu now automatically takes you to the values of the number of cycles.

The LCD now displays the currently set value of the number of cycles c (c_{is}). Now you have the possibility to change the values of the number of cycles c.

Changing the value of the number of cycles c:

✦ If you want to change the value of the number of cycles c move the activation and programming key back to the action area.

➡ In the LCD the next higher ($c_{is} + 1$) adjustable value of the number of cycles c is displayed. The green LED lights up as long as the activation and programming key is placed on the action surface; the other values of the number of cycles c run through one after the other. However, you can also remove the activation and programming key from the action area and bring it back there shortly afterwards to reach each value one after the other. If the final value of the number of cycles c of $c=30$ is reached and no value has been selected, the menu returns to $c=01$ and the cycle can be restarted.

✦ As long as the new chosen value for the number of cycles c (c_{new}) is displayed in the LCD remove the activation and programming key from the action area.

➡ The yellow LED disappears, the green LED and the LCD flash twice. The selected new value ($c_{new} = c_{is}$) of pause time h has now been accepted.

No changing of the value of the number of cycles c:

✦ If you do not want to change the value of the number of cycles c the activation and programming key must remain removed from the action area immediately after entering the PRO menu.

➡ The LCD and the green LED flash twice and the number of cycles c is displayed in the LCD.

✦ Insert the activation and programming key into the hole provided on top of LUB-V.

ⓘ The PRO menu can only be reached from ON mode (LUB-V switched on). When leaving the PRO menu you will return to ON mode.

ⓘ If you have made changes to the values of pause time h or number of cycles c in PRO menu and LUB-V is otherwise ready for operation (battery full and inserted as well as a cartridge fitted), LUB-V will immediately trigger the newly set dispense and start the newly set waiting time until the next dispenses.

✦ Insert the activation and programming key into the hole provided on top of LUB-V.

✦ Observe the back pressure values displayed on the LCD if they are of interest.

ⓘ During the dispensing process the green LED lights up; in addition, the stroke's counterpressure is displayed in the LCD.

The parameters that can be set for pause time h and the number of cycles c and their respective permissible values are specified as follows:

h = **Pause time** in hours (h).

The pause time can be set between 1 | 2 | 3 | ... | 240 hours.


The time counter integrated in the microelectronics of LUB-V starts counting the pause time h at the end of a successful and fully completed dispensing cycle.

c = **Number of cycles** within a dispensing cycle (c).

The number of cycles c can be set between 1 | 2 | 3 | ... | 30 strokes.

6.3.10 PRO menu, operating mode: empty time mode Et

The PRO menu allows you to change the settings of the LUB-V's dispensing behavior. Running empty time mode Et, you can change the emptying time Et in months. LUB-V automatically calculates the pause time between two cycles to reach the set emptying time in months.



✓ There is no fault or error at LUB-V.

✦ Remove the activation and programming key from the top of LUB-V and place it onto the action area. Hold the activation and programming key onto the action surface. Leave the activation and programming key on the action area until PRO is displayed in the LCD.

✦ Remove the activation and programming key from the action area as long as PRO is displayed.

➡ The LCD and the green LED flash twice. The LCD first displays the value of the emptying time Et (Et_{is}) currently set. You are now able to change the values of emptying time Et.

Changing the value of emptying time Et:

✦ If you would like to change the value of emptying time Et, move the activation and programming key back to the action area.

➤ In the LCD the next higher ($E_{t_{is}} + 1$) adjustable value of emptying time E_t is displayed. The green LED lights up as long as the activation and programming key is placed onto the action surface; the other values of emptying time E_t run through one after the other. However, you can also remove the activation and programming key from the action area and bring it back there shortly afterwards to reach each value one after the other. If the final value of emptying time E_t of $E_t=36$ is reached and no value has been selected the menu returns to $E_t=01$ and the cycle can be restarted.

✦ As long as the new chosen value for emptying time E_t ($E_{t_{new}}$) is displayed in the LCD remove the activation and programming key from the action area.

➤ The yellow LED disappears, the green LED and the LCD flash twice. The selected new value ($E_{t_{new}} = E_{t_{is}}$) of pause time h has now been accepted.

No changing of the value of emptying time E_t :

✦ If you do not want to change the value of emptying time E_t the activation and programming key must remain removed from the action area immediately after entering the PRO menu.

➤ The LCD and the green LED flash twice and emptying time E_t is displayed in the LCD.

✦ Insert the activation and programming key into the hole provided on top of the housing of LUB-V.

ⓘ The PRO menu can only be reached from ON mode (LUB-V switched on). When entering the PRO menu, you will return to ON mode.

ⓘ If you have made changes to the values of emptying time E_t in PRO menu and LUB-V is otherwise ready for operation (battery full and inserted as well as a cartridge fitted), LUB-V will immediately start the calculated waiting time until the next dispenses.

✦ Observe the back pressure values displayed on the LCD if they are of interest.

ⓘ During the dispensing process the green LED lights up; in addition, the stroke's counterpressure is displayed in the LCD.

The parameters that can be set for emptying time E_t and their respective permissible values are specified as follows:

E_t = **Emptying time** of a full cartridge in months (E_t).

The emptying time can be set between 1 | 2 | 3 | ... | 36 months.


The time counter integrated in the microelectronics of LUB-V starts counting the pause time at the end of a successful and fully completed dispensing cycle.

6.3.11 PRO menu, operating mode: impulse mode PUL

The PRO menu allows you to change the settings of the LUB-V's dispensing behavior. Running impulse mode PUL, settings can not be changed. An external control (PLC) in which LUB-V is embedded commands and controls the device, see chapters 6 and 8. The display shows PUL (impulse mode) for your information.

6.3.12 FIL menu

The FIL menu allows you to trigger a defined multiple dispense of LUB-V. The activation initiates a total of 40 pump strokes. This function enables you to prefill connected accessories (tubes, distributors,...) with the lubricant contained in the lubricant cartridge, especially during the initial start-up of LUB-V. However, the process can also be aborted manually at any time.



✓ There is no fault or error at LUB-V.

✦ Remove the activation and programming key from the top of LUB-V and place it on the action area. The yellow LED will light up. Leave the activation and programming key on the action area until FIL is displayed in the LCD. Remove the activation and programming key from the action area. The yellow LED disappears.

⇒ The LCD and the green LED flash twice. LUB-V starts dispensing. The green LED lights up during each dispense.

✦ If you do not want to cancel the process: Insert the activation and programming key into the hole provided on top of LUB-V.

⇒ LUB-V dispenses 40 strokes of lubricant.

✦ If you would like to cancel the process: Place the activation and programming key on the action area and wait until the end of a dispensing process (motor run).

⇒ CLR appears in the LCD.

✦ Remove the activation and programming key from the action area.





⇒ LUB-V stops the FIL command.

✦ Observe the back pressure values displayed on the LCD if they are of interest.

- ① During the dispensing process the green LED lights up; in addition, the stroke's counterpressure is displayed in the LCD.
- ① The FIL menu can only be reached from ON mode (LUB-V switched on). When you enter the FIL menu you will return to ON mode, even if you cancel FIL prematurely with CLR.

6.4 Error codes

The microelectronics integrated in LUB-V permanently monitor the status. In case of irregularities an addressed error message is displayed on the LCD. The red LED flashes every 5 seconds and signals an error.


LCD	Name	Description	Remedy
	Error E1	Cartridge empty	<ul style="list-style-type: none"> ✦ Place a new cartridge on LUB-V (see chapter 9.2). ① No confirmation of error necessary; it is automatically cleared after the remedial action.
	Error E2	Overload, the backpressure at the lubrication point is too high	<ul style="list-style-type: none"> ✦ Check the lubrication point and eliminate the fault's cause. ✦ Switch LUB-V off (OFF) and on (ON) again.
	Error E3	Undervoltage	<ul style="list-style-type: none"> ✦ Switch LUB-V off (OFF). ✦ Check the power supply of LUB-V. ✦ Switch LUB-V on (ON).
	Error E4	Fatal error	<ul style="list-style-type: none"> ✦ Disassemble LUB-V and return it to the manufacturer together with the lubricant cartridge and a description of faults. ① A fatal error usually concerns the electronics of LUB-V and cannot be repaired by you on site. ① The manufacturer's address can be found in chapter I.II.

7. Input and output signals - time control

LUB-V operates in hour mode -h- or empty time mode Et as a time-based and cycle-controlled lubrication system according to the values set in PRO menu.

7.1 Pin assignment - time control

PIN assignment		
PIN	Assignment	Colour
1	+24 V DC	brown
2	unallocated	white
3	ground	blue
4	output signal	black
Type: M12x1 female connector; 4-pin, A-coded		



LUB-V can be switched off completely by switching off the supply voltage. After reapplying the supply voltage LUB-V checks itself automatically but only operates after receiving an input signal from the PLC.

- ⓘ After a long standstill of LUB-V a "quick check" is recommended (chapter 6.3.6).
- ⓘ The output signal at PIN 4 can be tapped for further processing (e.g. indicator light or external control). The maximum permissible current output must not exceed $I_{max} < 20\text{mA}$. No inductive load (e.g. relay) may be connected!


7.2 Output signals and LCD messages - time control

LCD	Description	Output Signal (PIN 4)	Chapter
OFF	switched off	low, permanent	7.3
On	ready for operation	high, permanent	
E1	cartridge empty	0,5Hz square wave signal, permanent	
E2	overload	low, permanent	
E3	undervoltage	low, permanent	
E4	fatal error	low, permanent	

7.3 Output signals at PIN 4 - time control

LUB-V provides two output signals in hour mode -h (factory setting) via the electrical interface. If required, the operating states of LUB-V can be processed externally. Basically, the output signals can only be sampled and must not be subjected to inductive loads or low ohmic loads. Besides LCD and LED this also allows a status control from a distance.


Output signal high level (+24 V) at PIN 4:



Description:

A permanently and continuously present high level (+24 V) at PIN 4 means that LUB-V is ready for operation and there is no error. LUB-V will operate according to the settings made and will accordingly convey lubricant from the cartridge to the outlet.

Output signal low level (0 V) at PIN 4:



Description:


A permanent low level (0V) at PIN 4 means that LUB-V is either switched off or - if it is switched on - an error occurred. The error must be read out from the LCD of LUB-V (chapter 6.4). LUB-V does not pump lubricant!

8. Input and output signals - external control (PLC)

To command LUB-V via an external controller (PLC) it is necessary to switch LUB-V to pulse control mode PUL in PRO menu (chapter 6.3.8).

In pulse control mode LUB-V operates as a pulse-controlled lubrication system only if unalterable input signals (high level) are transmitted from the PLC to LUB-V via PIN 2 in a defined sequence. LUB-V signals the respective status to the PLC via high/low levels which can be tapped off at PIN 4 and thus enables comprehensive control or, by suitable programming of the PLC, differentiated evaluation of the different states. To integrate LUB-V into an external control one input and one output must be provided on the control side.

8.1 Pin assignment - external control (PLC)



PIN assignment (PLC)		
PIN	Assignment	Colour
1	+24 V DC	brown
2	Input Signal PLC → LUB-V	white
3	Ground	blue
4	Output Signal LUB-V → PLC	black
Type: M12x1 female connector; 4-pin, A-coded		

To electrically connect LUB-V to the PLC of your machine the device provides a 4-pin interface which is designed as a standard industrial M12x1 plug connection.

① LUB-V can be switched off completely in pulse control mode by switching off the supply voltage. The settings made are not lost. After reapplying the supply voltage LUB-V checks itself automatically but only operates after receiving an input signal from the PLC.

① To operate LUB-V via an external controller (PLC) in pulse control mode a program corresponding to the communication protocol must be created in the PLC. A basic flowchart for commanding LUB-V can be found in the appendix (chapter 11.4).

① The output signal at PIN 4 can be tapped for further processing (e.g. indicator light or external control). The maximum permissible current output must not exceed $I_{\max} < 20\text{mA}$. No inductive load (e.g. relay) may be connected!

① After a long standstill of LUB-V a manually triggered single dispense is recommended. (2 seconds signal).

8.2 Input signals - external control (PLC)

LUB-V provides the following unalterably defined control signals (input signals) which must be transmitted from the PLC to LUB-V via PIN 2 of the electrical M12x1 interface as high level (+24 V DC).


The control signals must be generated as high level (+24 V) by the external controller (PLC) over certain times with a tolerance of +/- 0.1 seconds.

Signal length in seconds	Description	Function	Chapter
2 high	Signal 2 seconds	1 stroke	8.2.1
12 high	Signal 12 seconds	FIL function	8.2.2
14 high	Signal 14 seconds	Error acknowledgement	8.2.3

ⓘ LUB-V in pulse control mode PUL only processes the control signals listed in the table up to a maximum length of 14 seconds. If a high level (+24 V DC) exceeds the defined tolerance level, LUB-V does not react. If a high level (+24 V DC) is applied to PIN 2 of the electrical interface for longer than 15 seconds the LCD will display --- and LUB-V does not react.

8.2.1 Control signal 2 seconds

The control signal 2 seconds triggers a single dispensing process. After a specified pause time this control signal can be repeated or another control signal can be sent. The operating states are output by LUB-V via PIN 4 as a high/low level and must be tapped and processed accordingly by the PLC.



T_p: Pause time
ML: Motor running time

Description:

✓LUB-V is properly connected to an external controller via the electrical interface and connected to the power supply.

✓Pulse control mode is activated on LUB-V and PUL is displayed on the LCD.

✓There are no errors; LUB-V is ready for operation; the green LED in the LCD flashes once every 5 seconds.

✦ LUB-V sends a permanent output signal (high level) to PIN 4 which indicates to the external control (PLC) that it is ready for operation. This output signal must be permanently and continuously present for >3 seconds to control LUB-V by a PLC.

✦ The control signal 2 seconds with a signal length of 2 (1.9 ... 2.1) seconds high level can be sent to LUB-V from the external control (PLC).

✦ While PIN 2 of LUB-V receives a high level input signal from the external controller (PLC) PUL is flashing in the LCD.

✦ Immediately after the control signal drops the motor run (ML) of LUB-V starts and 0.16 cm³ lubricant is conveyed to the outlet. Simultaneously, LUB-V sends a low level output signal to the external controller (PLC) to confirm the duration of the motor run (ML).

✦ The motor running time (ML) depends on various conditions, including the present or built up counterpressure in the hydraulic system and the temperature. The motor running time (ML) is 7...17 seconds.

✦ While the engine is running, the green LED in the LCD lights up and a numerical value of 1...70 is displayed in the LCD. It indicates the approximate back pressure in bar.

✦ At the end of an error-free and successful motor run (ML) the output signal at LUB-V changes from a low level to a high level.


ⓘ A new control signal can be sent from the external controller (PLC) at the earliest of >3 seconds after the motor run ended error-free and successfully. In the meantime, LUB-V does not process any control signals.

ⓘ In order to ensure a reliable and unambiguous recognition of the control signal a pause must be observed. The control signal 2 seconds requires a pause time (Tp) of at least 22 seconds between two identical or different control signals.

ⓘ If the integrated microelectronics of LUB-V have detected an error during or immediately after the motor run (ML), this is transmitted to the external controller (PLC) by the corresponding output signal (chap. 8.3). The error is additionally visualized by the correspondent LCD display with a permanently red flashing LED (section 6.4).

8.2.2 Control signal 12 seconds

The control signal 12 seconds triggers the FIL function (section 6.3.9) by the external control. A total of 40 dispensing operations are carried out automatically one after the other. After a certain pause time this control signal can be repeated or another control signal can be sent. The operating states are output by LUB-V via PIN 4 as high/low levels and must be tapped and processed accordingly by the PLC.



Description:

✓LUB-V is properly connected to an external controller via the electrical interface and connected to the power supply.

✓Pulse control mode is activated on LUB-V and PUL is displayed on the LCD.

✓There are no errors; LUB-V is ready for operation; the green LED in the LCD flashes once every 5 seconds.

✦ LUB-V sends a permanent output signal (high level) to PIN 4 which indicates to the external control (PLC) that it is ready for operation. This output signal must be permanently and continuously present for >3 seconds. This condition must be fulfilled to control LUB-V by a PLC.

✦ The control signal 12 seconds with a signal length of 12 (11.9 ... 12.1) seconds high level can be sent to LUB-V from the external control (PLC).

✦ While PIN 2 of LUB-V receives a high level input signal from the external controller (PLC) PUL is flashing in the LCD.

✦ Immediately after the control signal drops the motor run (ML) of LUB-V starts and 0.16 cm³ lubricant is conveyed to the outlet. Simultaneously, LUB-V sends a low level output signal to the external controller (PLC) to confirm the duration of the motor run (ML).

✦ The motor running time (ML) depends on various conditions, including the present or built up counterpressure in the hydraulic system and the temperature. The motor running time (ML) is 7...17 seconds.

✦ While the engine is running, the green LED in the LCD lights up and a numerical value of 1...70 is displayed in the LCD. It indicates the approximate back pressure in bar.

✦ At the end of an error-free and successful motor run (ML) the output signal at LUB-V changes from a low level to a high level for a short pause time P = 0.5 seconds.

✦ A total of 40 engine runs and dispenses will take place immediately one after the other. $40 \times 0.16 \text{ cm}^3 = 6.4 \text{ cm}^3$ lubricant is conveyed from the cartridge to the outlet.


ⓘ A new control signal can be sent from the external controller (PLC) at the earliest of >3 seconds after the motor run ended error-free and successfully. In the meantime, LUB-V does not process any control signals.

ⓘ In order to ensure a reliable and unambiguous recognition of the control signal a pause must be observed. The control signal 12 seconds requires a pause time (Tp) of at least 22 seconds between two identical or different control signals.

ⓘ If the integrated microelectronics of LUB-V have detected an error during or immediately after the motor run (ML), this is transmitted to the external controller (PLC) by the corresponding output signal (chap. 8.3). The error is additionally visualized by the correspondent LCD display with a permanently red flashing LED (section 6.4).

8.2.3 Control signal 14 seconds

The control signal 14 seconds is used to acknowledge error messages of errors E2 and E3. It is the only control signal that LUB-V can process when a low level output signal is sent. Regardless of the basic principle of remotely acknowledging an error it is essential to identify and eliminate the cause when an error message is present.



Description:

✓LUB-V is properly connected to an external controller via the electrical interface and connected to the power supply.

✓Pulse control mode is activated on LUB-V and PUL is displayed on the LCD.

✓There are no errors; LUB-V is ready for operation; the green LED in the LCD flashes once every 5 seconds.

✦ LUB-V sends a permanent output signal (high level) to PIN 4 which indicates to the external control (PLC) that it is ready for operation. This output signal must be permanently and continuously present for >3 seconds to control LUB-V by a PLC.

✦ The control signal 14 seconds with a signal length of 14 (13.9 ... 14.1) seconds high level can be sent to LUB-V from the external control (PLC).

✦ When the control signal ends the integrated microelectronics of LUB-V will automatically check itself:

+ If this internal check is **successful**, the output signal at LUB-V changes from a low level to a high level; error E2 or E3 is thus acknowledged and LUB-V is ready for operation again. The LCD briefly displays CLR and then PUL.

- If this internal check is **not successful**, LUB-V continues to send a low level output signal. The error (E4) is still present. The error is still displayed in the LCD, the red LED continues to flash permanently. For further measures in this case: chap. 8.3.4.

ⓘ A new control signal can be sent from the external controller (PLC) at the earliest of >3 seconds after the motor run ended error-free and successfully. In the meantime, LUB-V does not process any control signals.


ⓘ Regardless of the basic principle of remotely acknowledging an error, it is essential to identify and eliminate the cause when an error message is occurs.

8.3 Output signals/LCD messages - external control (PLC)

LCD	Description	Output signal (PIN 4)	Chapter
OFF	switched off	low, permanent	6.3.3
PUL	ready for operation	high, permanent	8
PUL flashing	received control signal	high, permanent	8
01...70	dispensing process	low, 7...17 seconds	8
E1	cartridge empty	0,5Hz square wave signal, permanent	8.3.1
E2	overload	low, permanent	8.3.2
E3	undervoltage	low, permanent	8.3.3
E4	fatal error	low, permanent	8.3.4

8.3.1 Error E1 (empty level) - external control (PLC)

LUB-V is equipped with a sensor which detects the empty level of the lubricant cartridge. After reaching the empty level, LUB-V no longer dispenses lubricant. This ensures that no air enters LUB-V or the lubricant lines. The empty state message (E1) is transmitted to the external control (PLC). For this purpose, a separate, unique output signal is provided which can be easily and reliably detected by the external control (PLC).



Description:

✓LUB-V is properly connected to an external controller via the electrical interface and connected to the power supply.


✓Pulse control mode PUL is activated on LUB-V, E1 is displayed in the LCD and the red LED lights up.

✦ Error E1 (empty state signal) can only occur immediately after a dispense.

✦ Error E1 (empty state signal) must not and cannot be acknowledged. Remedial action is described in chapter 9.2. When removing the cartridge LUB-V sends a permanent square wave signal as output signal to PIN 4.

ⓘ LUB-V does not process any control signals until all errors have been eliminated.

The transition of the output signals when changing a cartridge on LUB-V in switched-on state is shown and described below:



- Z1: *Removing the empty cartridge*
 Z2: *Mounting the new cartridge*

Description:


- ✓ LUB-V is properly connected to an external controller via the electrical interface and connected to the power supply.
- ✓ Pulse control mode PUL is activated on LUB-V, E1 is displayed in the LCD and the red LED lights up.

- ✦ The empty cartridge is detected after a dispense, the output signal of LUB-V is initially a 0.5Hz square wave signal (empty state signal) (0/+24 V).
- ✦ Z1 indicates the period of removing the empty cartridge. The output signal of LUB-V now changes from a 0.5Hz square wave signal to a permanent low signal (0V).
- ✦ Z2 indicates the period of screwing on a new, full cartridge. The output signal of LUB-V now changes from a permanent low signal (0V) to a permanent high signal (+24V). In this way LUB-V signals to the external controller (PLC) that it is ready for operation again.
- ✦ If the empty state signal has occurred during the execution of the control signal 12 seconds the outstanding strokes are continued after the new cartridge has been screwed on.

- ⓘ LUB-V does not process any control signals until all errors have been eliminated.

8.3.2 Error E2 (overload) - external control (PLC)

Error E2 (overload) signals a hydraulic overload during a dispensing process, e.g. if the maximum pressure is exceeded.



Description:

✓LUB-V is properly connected to an external controller via the electrical interface and connected to the power supply.

✓LUB-V has been successfully controlled by the external control (PLC) immediately before the occurrence of error E2 and has (attempted to) perform a dispensing operation.

✓Pulse control mode PUL is activated on LUB-V, E2 is displayed in the LCD and the red LED lights up.


✦ When the maximum permissible pressure is reached during or after a dispense, LUB-V sends a permanent output signal as low level (0 V) to PIN 4 for external control (PLC).

✦ The error E2 (overload) must be acknowledged with the control signal 14 seconds (chapter 8.2.3) after elimination of the cause(s).

ⓘ LUB-V does not process any control signals until all errors have been eliminated.

8.3.3 Error E3 (undervoltage) - external control (PLC)

Error E3 (undervoltage) indicates that the power supply is not within the specified parameters.



Description:

✓LUB-V is properly connected to an external controller via the electrical interface and connected to the power supply.

✓Pulse control mode PUL is activated on LUB-V, E3 is displayed in the LCD and the red LED lights up.


✦ If the supply voltage is too low, LUB-V sends a permanent output signal as low level (0 V) to PIN 4 for external control (PLC).

✦ Error E3 (undervoltage) must be acknowledged with the control signal 14 seconds (chapter 8.2.3) after elimination of the cause(s).

ⓘ LUB-V does not process any control signals until all errors have been eliminated.

8.3.4 Error E4 (fatal error) - external control (PLC)

Error E4 (fatal error) indicates that the integrated microelectronics has detected a critical error and that LUB-V is not operating within the valid parameters. The cause can be mechanical, electronic or any other influencing variable.



Description:

- ✓ LUB-V is properly connected to an external controller via the electrical interface and connected to the power supply.
- ✓ Pulse control mode PUL is activated on LUB-V, E4 is displayed in the LCD and the red LED lights up.

- ✦ In an (internal) diagnosis, the critical (rare) error E4 has been detected.
- ✦ Error E4 cannot be corrected by you on site and cannot be acknowledged by you on LUB-V!
- ✦ Remove LUB-V with the lubricant cartridge screwed on and return the complete lubrication system to the manufacturer with a detailed description of the fault. The manufacturer's address is given in chapter I.II.

ⓘ Do not open LUB-V without authorization! Observe the relevant notes and regulations for proper use (section 2.5) and warranty (section 2.6).

9. Maintenance and disposal

✦ Before starting any maintenance work, inform yourself about the general safety instructions (see chapter 2) and observe the relevant local and operational safety regulations.

✦ Do not deactivate any protective device without authorization!

9.1 Maintenance schedule

The following maintenance schedule must be observed for LUB-V:

Maintenance	Commissioning	After 500 hours or after 3 months	Annually	If required
Cleaning	X	X	X	X*
Visual check	X	X	X	X*
Cartridge change	X**		X***	X*

* Depending on operating conditions and lubricant consumption

** Depending on delivery status (ordered version)


*** after 2 years at the latest

9.1.1 Visual check

- ✦ Check the entire lubrication system (LUB-V and any connected accessories including tubes and distributors) for external damage (e.g. loose or loosened tubes) by a thorough and conscientious visual inspection.
- ✦ Check the condition of the lubrication point for correct supply of lubricant.
- ✦ Replace damaged or defective parts immediately to ensure permanent lubrication.
- ✦ Check the filling level of the cartridge on LUB-V.
- ✦ Check possible error messages on LUB-V and remedy the causes accordingly.

9.1.2 Cleaning


- ✦ Clean LUB-V from dirt using suitable cleaning agents (e.g. absorbent towels, cloths).


	NOTICE
	<p>Compressed air can damage the seals of LUB-V as well as transport dirt and foreign bodies into LUB-V or the lubricant.</p> <ul style="list-style-type: none"> • Do not use compressed air to clean LUB-V.


9.1.3 Recommissioning after maintenance

- ✦ Reinstall all safety devices and make sure that no tools remain in the danger area.
- ✦ Check if LUB-V is switched on.
- ✦ Carry out a "Quick Check" (test run) using the RUN command (section 6.3.6).

9.2 Cartridge change

	NOTICE
	<p>Only use original lubricant cartridges with lubricant approved by the manufacturer.</p> <ul style="list-style-type: none"> • Observe the maximum shelf life of lubricant filled in cartridges.

	NOTICE
	<p>It is not possible to refill empty or opened lubricant cartridges.</p>


	NOTICE
	<p>Make sure you use the same lubricant in the new cartridge that is already in use.</p> <ul style="list-style-type: none"> • Compare the data on the lubricant cartridge.

Changing the lubricant cartridge of LUB-V is very easy.

The cartridge needs to be changed if it is empty or if the service life of the lubricant has been exceeded. The cartridge can be changed during normal operation of LUB-V. Besides the cartridge change no further action is needed.

✓LUB-V has a fault (error E1); the red LED flashes every 5 seconds.

1



Remove housing from power unit

✦ Separate the housing from the power unit by turning the retaining ring counterclockwise.


ⓘ Make sure that no dirt, water or foreign bodies enter the lubricant inlet.

2

Remove empty cartridge

✦ Turn the empty cartridge clockwise to remove it.

3




Remove cartridge cap

✦ Turn the cap of the lubricant cartridge counterclockwise and pull it off.

ⓘ Pay attention to cleanliness when carrying out the work. Be sure to prevent dirt, liquids and foreign bodies from entering the cartridge.

4




Mount lubricant cartridge

- ✦ Place the full lubricant cartridge on LUB-V (label facing front).
- ✦ Turn the lubricant cartridge clockwise onto LUB-V.

ⓘ The end position is reached after two full rotations when the label of the lubricant cartridge is aligned with the front of LUB-V.

5



Assemble housing on power unit

- ✦ Place the dismantled housing on LUB-V and press it onto the power unit.
- ✦ Fasten the housing to the power unit by turning the retaining ring clockwise.

ⓘ The retaining ring must snap into place when turning and be completely tightened.

✦ Carry out the work as described above.

➡ If an error was displayed in the LCD before changing the cartridge, the message will now disappear, as will the flashing red LED. A separate confirmation is not necessary. The green LED flashes briefly every 5 seconds.

➡ LUB-V automatically returns to the last active mode (ON or OFF).

ⓘ If the empty state of the cartridge (error E1) was reached during a dispensing cycle, it is interrupted and continued automatically after completing the work explained above.

9.3 Disposal

✦ When disposing LUB-V and empty or opened cartridges follow the relevant national regulations in force.

✦ When disposing LUB-V observe the relevant safety data sheets and disposal instructions for the individual components.

ⓘ It is not possible to refill empty lubricant cartridges.

2. Released accessories


The present LUB-V can be considerably extended by the extensive system and accessory program from use as a single point lubricator. This may necessitate changes to the factory and/or the default settings of LUB-V to ensure reliable and proper operation of LUB-V combined with the hydraulically connected accessories.

Amongst others, cartridges filled with different lubricants, brackets, splitters and progressive distributors are available.

For more information please contact the manufacturer or visit its website www.G-LUBE.com.

10.1 Lubricants

Only use lubricants approved by the manufacturer Gruetzner GmbH in the original cartridges developed and manufactured exclusively for LUB-V.

	NOTICE
	<p>The lubricant used in each case differs according to the application. The respective designation can be found on the label of the cartridge.</p>


Further information on lubricants, documentation and safety data sheets can be obtained directly from the manufacturer Gruetzner GmbH.

10.2 Tube lengths

Generally it is recommended to install LUB-V as close as possible to the consumer (lubrication point). Ideally, this should be done directly at or on the lubrication point. In cases where this is not possible due to the installation space or for reasons of reachability or accessibility, tubes can also be used between LUB-V and the lubrication point (or distributor).

The tube length shall not exceed 5 meters, the inner tube diameter shall not be lower than 4 mm. The maximum tube length depends on a wide range of parameters such as temperature, application and viscosity of the lubricant used.

3. Appendix 3.1 Dimension sheet and installation dimensions



3.2 EC/EU Declaration of conformity

EC declaration of conformity



**Declaration of conformity
according to EC machinery directive 2006/42/EC as of 17. May 2006**

The manufacturer or authorised representative*

Gruetzner GmbH, Kohlenhofstr. 60, 90443 Nuremberg, Germany

hereby declares that the following lubrication systems

Product designation: LUB-V
Type designation: LUB-V-1, LUB-V-2

comply with the essential requires of EC directive 2006/42/EC.

The following harmonized standards have been applied:

EN 12100:2011 Saftey of machines

Additionally the systems comply with the regulations for electromagnetic compability according to 2004/108/EC.

The following harmonized standards have been applied:

EN 61000-6-2, EN 61000-6-4 electromagnetic compability

Authorised representative for the compilation of technical documents:

Volker Grützner, CEO, Gruetzner GmbH, Kohlenhofstr. 60, 90443 Nuremberg, Germany

Nuremberg, 01.06.2015

Volker Grützner, CEO

*must be based within the EU

Gruetzner GmbH

Kohlenhofstr. 60

90443 Nuremberg, Germany

Tel: +49 911 277399-0

Fax: +49 911 277399-99

info@G-LUBE.com

www.G-LUBE.com




GRUETZNER
AUTOMATIC LUBRICATION



3.3 Spare parts

Art. no.	Designation	Application

3.4 Flow chart impulse mode PUL



The adjoining figure shows the basic flow chart for control signal 2 seconds (chapter 8.2.1) which triggers a stroke in impulse mode as well as possible errors.

The flow chart shall help you creating a customized program for your external control (PLC). This program is essential to completely control and run LUB-V properly.

i Both PIN 2 and 4 refer to the electrical interface M12x1 (chapter 8.1)

i Proceed the same way when creating a program to trigger the FIL function (chapter 8.2.2) but change control signal 2 seconds to control signal 12 seconds.



GRUETZNER
AUTOMATIC LUBRICATION



G LUBE



SOLO LUBE

AUTOMATIC LUBRICATION



LUB 5



LUBRICUS

Gruetzner GmbH

Kohlenhofstr. 60 • D - 90443 Nuremberg, Germany
info@G-LUBE.com • www.G-LUBE.com