CHAPTER 10 - ACCESSORIES ARV 21


ARV 60 // Tube connector






- Tube connector for positive connection torque transmission to 1" tube
- \rightarrow ARV 60.1042: one-part tube connector with screws and lock nuts.
- ightarrow ARV 60.1044: galvanised half shells with screws and lock nuts.

ARV 60.1042 ARV 60.1044









Version	Type no.	Info	m [kg]
ARV 60.1042	81660.1042.3415	Tube connector // Incl. 4 screws and lock nuts	0,6
ARV 60.1044	81660.1044.3410	Tube connector // Incl. 2 screws and lock nuts	1,0